


Z Star Juice Extractor



INSTRUCTION BOOKLET

SAVE THIS MANUAL-KEEP IT HANDY FOR QUICK REFERENCE READ INSTRUCTIONS BEFORE USING

Table of contents

•	Important Safety Instructions
•	Warranty2
•	Warranty Registration Card ·····In sert
•	Juicer Part Description4
•	Z Srar Assembly and Operation5
•	Disassembling the Z Star ·····5
•	Cleaning the Z Star ·····6
	Trouble Shooting ·····6
	When you need service

©2003 Tribest Corp.

No copies, transmission, or translation into other languages of this manual by any means whthout written permission of Tribest Corp. is allowed. All rights are reserved.

Important Safety Instructions

- 1. Please read all instructions carefully.
- 2. While the machine is in operation, avoid contact with its moving parts.
- 3. Close supervision is necessary when any appliances are used by or near children.
- 4. Do not put any articles such as spoons, forks or knives into the feeding chute.
- 5. It is very dangerous to place fingers into the feeding chute while it is in operation. Make sure to always use the provided plunger to push down materials.
- 6. Please refer to "When You Need Service" in case your juicer is functioning abnormally.
- Do not disassemble any parts other than those necessary for normal operation or cleaning of your juice extractor
- 8. Do not use hot or boiling water (above 40 degree C) to clean the unit and parts. Deformation or other damages will result.
- 9. Do not use any bleach or harsh chemicals.
- 10. This machine is made for household use only.
- 11. Please refer to the "INSTRUCTIONS" before use
- 12. Do not use the appliance for any other than its intended use.

SAVE THESE INSTRUCTIONS

Warranty

We warrant to you, the end-user customer who has properly registered after purchasing the Z Star Juice Extractor for a valuable consideration, that the plastic parts and motor will be free from defects in materials and workmanship for a period of 1 year from the date of purchase. All other parts, including but not limited to the Juice and Pulp Containers and the Plastic Plunger are not subject to any warranty. Warranty does not cover normal wear and tear.

In order for you to receive the benefits of this warranty, you are requied to complete and mail the warranty registration card, containing all the requested information, to us within ten (10) days following the purchase of your Z Star.

- 1. No warranty will be provided until after we have actually receive the enclosed warranty registration card, containing all the requested information, within ten (10) days of the date of original purchase. The warranty is only good for the original purchaser for value. This warranty is non-transferable.
- 2. If the Z Star exhibits defects while in normal household use, we, upon our actual receipt of a written notice of such defects from you during the warranty period, we will, at our option, either repair or replace the Z Star which prove to be defective, However, we have no such obligation to repair or replace until after you have, by insured mail and in protective packaging*, delivered the Z Star to the location of your service center as set forth, Replacement Z Star may be either new or like new. Z Star may contain re-manufactured or reconditioned parts,, which are equivalent to new in performance or may have been subject to incidental use.
- 3. We do not warrant that the operation of the Z Star will be uninterrupted or error free. In no event shall our liability exceed the retail value of the Z Star.
- 4. All warranty and repair services must be performed at a warranty sevice center, which is located within the country where the machines was originally purchased. However, in the event that: [i] the machine must be serviced at a sevice center, which is not located within the country where the machine was purchased; or [ii] there is no service center within the country where the machine is located and must be shipped to a service center in another country, then those service centers are responsible for the parts and service only, and any and all costs relating to the shipping, delivery and handling of the machine to and from those service center shall be the sole responsibility of the owner.

This warranty does not cover defects resulting from: [a] failure to operate the Z Star in accordance with the instructions; [b] use of parts or supplies not provided or authorized by us; [c] negligent, improper or inadequate maintenance; [d] service performed or attempted by unauthorized service person; [e] damages, accidental or otherwise to the Z Star, which are not directly caused by us or the manufacturer; or [f] damages resulting from abuse, tampering, misuse, commercial use, or unauthorized modification of the Z Star.


WE MAKE NO OTHER EXPRESS OR IMPLIED WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL TO THE EXTENT ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR IMPLIED WARRANTY OR CONDITION OF MARCHANTABILITY IS LIMITED TO ONE (1) YEAR. In the event that such limitation or exclusion on the duration of an implied warranty is not allowed in the state or county wherein you reside, the above limitation or exclusion will not apply. This warranty give you specific legal rights and protection, and you might also have other rights that vary from state to state, or country to country.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL WE BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT, OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some state or counties may not allow the exclusion or limitation of incidental or consequential damages. If you reside in such a state or county, the above limitation or exclusion may not be applicable.

Do not send your Z Star back to the service center whthout return authorization.

^{*}Save Original Shipping Box

Juicer Part Description



Z Star Assembly and Operation:

- 1. Place the base of the Z Star at the edge of the counter or table top.
- 2. Fit the teeth of the Table Clamp into the groove in the base of the Z Star. Secure the juicer to a counter or table top by tightening the screw.
- 3. Attach the Handle to the base.
- 4. Place the Auger into the Auger Housing.
- 5. Slide the Auger Housing into the Auger Housing Retaining Ring, While holding the housing stable, trun the Auger Housing Retaining Ring to lock the Auger Housing in place.
- 6. Put the Juicing Screen into the front end of the Auger Housing.
- 7. Make sure the Juicing Nozzle is securely in place inside the Screen Locking Cap. Put the Screen Locking Cap over the screen and lock into position.
- 8. Insert the funnel into the Auger Housing and place the Juice Container underneath the juice outlet. You will need a separate container to catch the pulp.

Disassembling the Z Star

- 1. Unlock and separate the Screen Locking Cap from the unit.
- 2. Pull to remove the Juicing Screen.
- 3. Turn the Auger Housing Retaining Ring to unlock and separate the Auger Housing and Auger from the Base.
- 4. Pull out the Auger from the Auger Housing.

Cleaning the Z Star

- 1. Be sure to clean and properly store the parts of the unit after every operation. When the Screens are not cleaned after use, the residue can get dried, blocking the holes from filtering and juicing.
- 2. Use lukewarm water with mild detergent. Do not use hot water or any harsh chemicals such as bleach. It can result to deformation of parts.
- 3. To remove colored stains, soak parts in 70% White Wine Vinegar and 30% Water.

Trouble Shooting

Symptom	Check to see if:
Loud Noise:	* the unit is leveled on a flat surface
Difficulty in feeding foods into the	* materials need to be cut into smaller
machine:	lengthwise pieces.
The Auger Housing does not fit onto	* there are any foreign materials
the main body	inside.
Juice leaks form the back of the	* the Auger Ring is loose and try
Auger Housing	reassembling.
	* you have not overloaded the unit;
	reduce the amount of material being
	put.

	PRODUCT STANDARD
ITEM	VEGETABLE JUICER
MODEL	Z-510
SIZE	110MM×205MM×345MM
WEIGHT	2KG

Для заметок					

Для заметок				

Условия гарантии

Гарантия предоставляется владельцу соковыжималки Z-Star Z-510. На пластиковые и металлические детали гарантия составляет 1 месяц с даты покупки. На остальные детали, включая ёмкость для сока, щетку для чистки, пластиковый толкатель, гарантия не распространяется. Также гарантия не распространяется на естественный износ любых деталей, включая шнек и сетку для сока. Если во время использования соковыжималки в нормальных условиях были обнаружены дефекты, фирма, согласно фактической дате получения письменного уведомления о дефектах в течение гарантийного периода, несет ответственность за замену или ремонт устройства.

Данная гарантия не распространяется на повреждения в результате:

- 1. Неправильного использования устройства, несоблюдения инструкций по эксплуатации.
- 2. Использования принадлежностей, не поставляемых производителем или уполномоченным изготовителем.
- 3. Ремонта или технического обслуживания в неуполномоченной компанией Tribest ремонтной организации.
- 4. Повреждений, которые не были вызваны производителем, в том числе повреждений при транспортрировке.
- 5. Несчастного случая, злоупотребления, порчи, неправильного обращения с устройством.
- 6. Внесения несогласованных с производителем изменений в конструкцию.
- 7. Использования устройства в коммерческих целях.

Приобретайте официально поставляемую продукцию Tribest — то есть ту, которая была предназначена фирмой Tribest для реализации на территории Российской Федерации и официально ввезена в Россию уполномоченным импортером. Официально поставляемая продукция комплектуется руководством по эксплуатации на русском языке, маркируется уникальным серийным номером с кодом импортёра, а также поддерживается электронной гарантией изготовителя по серийному номеру. При нелегальном ввозе продукции на территорию Российской Федерации нарушаются нормы таможенного законодательства и законодательства о защите прав интеллектуальной собственности. Авторизованные сервисные центры Tribest не осуществляют бесплатную гарантийную поддержку продукции Tribest, нелегально ввезенной в Россию. Вы имеете право на гарантийное обслуживание только в тех авторизованных сервис-центрах Tribest, контактная информация которых указана в данном гарантийном талоне.

Чтобы удостовериться, что изделие Tribest предназначено для продажи на российском рынке и поддерживается гарантией Tribest в указанных в данном гарантийном талоне сервисных центрах, вы можете проверить его серийный номер и получить соответствующее подтверждение от сервисцентра.

Гарантийный талон

Контактная информация авторизованного сервис-центра:

OOO «Все Соки»; www.vsesoki.com; 8-800-3333-627 (звонок бесплатный)

г. Москва, ул. 8-ой проезд Марьиной рощи, дом 30, строение 3.

Тел.: +7 (495) 134-11-44.

г. Санкт-Петербург, Витебский проспект, дом 3.

Тел.: +7 (812) 389-33-66.

Электронная почта: remont@vsesoki.com

Быстро и удобно оставить заявку на ремонт можно через форму на сайте: www.vsesoki.ru/remont

Для ускорения процесса гарантийного обслуживания направьте на электронную почту авторизованного сервис-центра письменное уведомление с подробным описанием дефекта устройства, приложенными фото или видео, отражающими суть проблемы. В письме укажите свои контактные данные и нижеперечисленную информацию (заполняется продавцом):

WIOДЕЛЬ:	
Серийный номер (Serial no):	
Фирма-продавец:	
Дата продажи:	(печать или штамп продавца)
Гарантийный талон будет являться недейств или неверного заполнения, а также отсутств покупателя!	•
С условиями гарантии ознакомлен и согласе	ЭН

(подпись покупателя)



Tribest Corporation
1143 N. Patt St., Anaheim, CA 92801
toll free: 888-254-7336 | tel: 714-879-7150
www.tribest.com | service@tribest.com

Представительство в России
Компания «Все Соки»
www.VseSoki.ru | info@VseSoki.com